

Northbound Interface



Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

[To the certification exam](#)

Northbound Interface (NBI) - is a InfiMONITOR's programming interface for integration with the higher-level NMS (Network Management System). Thus, NBI allows to perform integration to the existing monitoring infrastructure.



NOTE

Integration with InfiMONITOR is performed through software. For more detailed information please refer to the documentation of your NMS.




Figure - Monitoring Infrastructure

Northbound interface is implemented as REST API, through which the following data can be obtained from InfiMONITOR:

- Lists of:
 - **Links** - represented as hosts, interfaces and vectors. Vector is a part of link acting in one direction. Each link consists of two vectors for up and down streams.
 - **Hosts** - represented as hosts name and **UUID**.
 - **Interfaces** - represented as interfaces name, UUID and IP-address.
 - **Vectors** - represented as UUID and link type.
 - **Events** - generated for host in accordance with the rule.
- The current parameters values obtained during the last polling cycle:
 - **Hosts.**
 - **Interfaces.**
 - **Vectors.**
- Parameters values for the specified time period:
 - **Hosts.**
 - **Interfaces.**
 - **Vectors.**

Access to NBI

In order to obtain the link to the NBI go to the section "System" → "Integrations". For authorization use the access key noted in the "API key" field.

Integrations

REST API : <https://192.168.103.200/api/nbi/swagger-ui.html>API key :

Figure - Link to the InfIMONITOR data

Find out more about REST API structure through the link above. Here you can manually execute queries for which you need to authorize with "API key".

NMS North Bound Interface

REST API

event-controller : Event Controller

Show/Hide | List Operations | Expand Operations

GET	/api/nbi/v1.beta/events	getEvents
-----	-------------------------	-----------

history-controller : History Controller

Show/Hide | List Operations | Expand Operations

host-controller : Host Controller

Show/Hide | List Operations | Expand Operations

interface-controller : Interface Controller

Show/Hide | List Operations | Expand Operations

link-controller : Link Controller

Show/Hide | List Operations | Expand Operations

parameter-value-controller : Parameter Value Controller

Show/Hide | List Operations | Expand Operations

vector-controller : Vector Controller

Show/Hide | List Operations | Expand Operations

Figure - REST API Structure

Integration examples



NOTE

You may download integration examples from the following link: <https://github.com/infinetwireless/infimonitor-nbi-examples>

SNMP Traps

InfIMONITOR may send SNMP Traps to higher-level NMS to increase reaction speed on events.



NOTE

MIB databases must be imported into your NMS to ensure proper message reception - <https://ftp.infinet.ru/pub/INMS/MIBS/>

Parent MIBs - <https://ftp.infinet.ru/pub/Firmware/MIBS/>

In order to configure SNMP Traps sending go to the section "System" → "Integrations". There are the following parameters:

- "Engine Id" - unique identifier allows NMS to recognize messages, received from InfIMONITOR. Can't be changed.
- "Notification limit" - sending limit expressed in maximum quantity of messages which may be sent during 1 second. In case of messages number over the limit, they will be sent during the next second.
- "Min. severity" - severity minimum level. If severity level of event is lower than specified then a message won't be sent.
- Receivers - InfIMONITOR may send messages to several monitoring systems at the same time. Values of the following parameters must be set:
 - NMS IP address;
 - network port;
 - SNMP version.

Engine Id :

Notification limit : notis/sec.

Min severity : ▼


Active	Ip	Port	Parameters	
<input checked="" type="checkbox"/>	192.168.1.2	162	V2C	

Figure - SNMP Traps configuration