

### Subslot

- Subslot – Time frame divides into Uplink and Downlink slots. In its turn, each slot divides into subslots. Each subslot intended for different devices. The purpose of subslots – data transfer from several CPEs within single Uplink slot in PtMP topology