

Packing List




Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

[To the certification exam](#)

This section describes the components that are supplied by default with the Quanta 5 / Quanta 6 models. Before the installation, please make sure you have all necessary parts and accessories.

Q5-28, Q5-25, Q5-23, Q5-E, Q6-28, Q6-25, Q6-E packing list

- Outdoor unit (ODU).
- Power supply.
- Cable gland (x2).
- Shielded RJ-45 connector.
- Unshielded RJ-45 connector.
- Mounting kit - universal assembling kit for mounting the ODU on standard pole, wall or thick pipe (vertical/horizontal).
- Power cord - the model depends on the region, according to the Purchase Order.



Q5-18, Q6-18 packing list

- Outdoor unit (ODU).
- Power supply.
- Cable gland.
- Shielded RJ-45 connector.
- Unshielded RJ-45 connector.
- Power cord - the model depends on the region, according to the Purchase Order.
- Nut M6 DIN 934 A4 (x2).
- Washer 6 flat (x2).
- Washer 6 spring (x2).
- Threaded rod M6x90 (x2).
- Bracer.