## **Packing List**



Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

To the certification exam

This section describes the components that are supplied by default with the Quanta 5 / Quanta 6 models. Before the installation, please make sure you have all necessary parts and accessories.

## Q5-28, Q5-25, Q5-23, Q5-E, Q6-28, Q6-25, Q6-E packing list

- Outdoor unit (ODU).
- Power supply.
- Cable gland (x2).
- Shielded RJ-45 connector.
- Unshielded RJ-45 connector.
- Mounting kit universal assembling kit for mounting the ODU on standard pole, wall or thick pipe (vertical/horizontal).
- Power cord the model depends on the region, according to the Purchase Order.



## Q5-18, Q6-18 packing list

- Outdoor unit (ODU).
- Power supply.
- Cable gland.
- Shielded RJ-45 connector.
- Unshielded RJ-45 connector.
- Power cord the model depends on the region, according to the Purchase Order.
- Nut M6 DIN 934 A4 (x2).
- Washer 6 flat (x2).
- Washer 6 spring (x2).
- Threaded rod M6x90 (x2).
- Bracer.