

User accounts



Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

[To the certification exam](#)

InfiMONITOR - the multiuser system with the access privileges assignment. For each operator of the monitoring system separate authorization account for the web-interface can be created. The access privileges can be assigned to a single account or to the group of accounts.

Account list of the users and groups is available in the section "Settings" -> "Users and groups". For each account the following parameters values are set:

- "Name" - account name most fully describing the user
- "Email" - the user's email address
- "Login" - the user's login
- "Permissions" - access rights for the web-interface sections.

Settings / Users and groups

Server date and time: 2016-04-13, 16:56:10

Search...		Add user		Add group	
Name	Email	Login	Permissions		
Administrator		admin	settings, history, ...		

Figure - The users and group account list

Administrator account

By default, **InfiMONITOR** has an administrator account with the name "*admin*" and with the following features:

- The administrator account login can't be changed
- The administrator account can't be removed.

User adding

In order to add a new user click the "**Add user**" button. The window with the following fields will appear on display:

- "Full Name" - account name
- "Login" - the user's login for authentication in the web-interface
- "Email" - email address for automatic incidents notification
- "Password" - authentication password
- "Activated" - the account state: enable/disable. The disabled account doesn't allow to pass authorization for the web-interface
- "Permissions" - the access privileges to the **InfiMONITOR** sections, which are provided individually or inherited from group including the account.




Figure - The user account addition

Group adding

In order to add a new group click the **"Add group"** button. The window with the following fields will appear:

- *"Group name"* - the group name, for example, the department name
- *"Permissions"* - the access privileges to the **InfimONITOR** sections to be used within the group
- *"Accounts in group"* - the users accounts in group. In order to add a new account, find it in the list and click the **"Add Account"** button.

New Group

Group Name :

Permissions

☐ Network Monitoring

☐ Reports

☐ Settings

Accounts in group

Name	Login
There are no items to display	

Figure - The group addition

The users and groups accounts deletion and editing

It is possible to delete a one account or several users and groups accounts simultaneously:

- One account deletion - in the list mouse over the user or group account you want to delete. The account will be highlighted and the **"Edit"** for editing and the **"Delete"** for deletion buttons will appear in the line
- Several accounts deletion - with a special checkbox in the list select those users or groups accounts you want to delete. After that the following buttons will appear at the bottom of the page:
 - **"Delete"** - to delete the selected users and groups accounts
 - **"Move"** - to move the selected users accounts to other group
 - **"Exclude"** - to exclude the users from the selected group.