## **Command Line**

The "Command Line" emulates command line interface in the Web interface. This allows managing and monitoring the device by using all the commands and functions that are available via standard CLI. In order to run one or a set of WANFIeX commands, type them in the command field and then click the "Execute" button. The output of the commands is displayed in the section above the command field.

```
InfiMUX Master#console>system uptime: config show
Uptime: 02:36:04
Last reboot reason: unexpected restart

**** Please change default Login and Password !!! ***
# R5000 MMPIXEX M9501-MINIV1.90.46 * Aug 28 2020 08:22:49 * SN:306190

#Environment
set CONFIG GEMERATED "WEB INTERFACE"

#System parameters
sys name InfiMUX Master
sys prompt InfiMUX Master
sys prompt InfiMUX Master
sys prompt InfiMUX Master
sys user root

#Interfaces parameters
ifc Log 127.0.0.1/32
ifc eth0 media auto up
ifc eth0 media auto up
ifc eth2 media auto up
ifc eth2 media auto up
ifc eth4 media auto up
ifc eth5 10.10.15/24

#QOS manager
quo option dollp rtp nodscp icmp

#MAC Switch config
switch group 2 add 1 eth5
    # useless group 2
switch group 2 add 1 eth5
    # useless group 2
switch group 2 start

switch start

#WEB configurator
webcfg start -lang=ru

#LLDP parameters
lldp eth0 enable txrx
lldp eth0 enable txrx
lldp eth0 enable txrx
lldp eth3 enable txrx
lldp eth4 enable txrx
lldp eth5 enable txrx
```

System Info
System Config
System Log
License Info
Reset All Counters
Routing Table
Switch Statistics
IGMP Statistics
Interface Table
Radio Statistics
Link Status
Radio Scanner
Traffic Show

Command: system uptime; config show

Execute Clear All Fields

In the "Command Line" the commands are only executed, but not saved into the configuration, while in "Extra commands" section from "Basic Settings" menu, the commands are executed and saved into the configuration.