
Web GUI Access

When you power on the unit, WANFIeX OS starts automatically and Web management is enabled by default so, in order to access the unit via Web browser type in the address bar the default address: 10.10.10.1/24.



The system allows concurrent login sessions via Web interface.

On the login page, you can type any username and any password and click Login:



NOTE

Please change the credentials you have just inserted with a permanent username and password for it after the first log in. In order to change the creden tials proceed to the "Basic Settings" - "System Settings" section.

The default language is English. After the authentication step, the language can be changed into Russian, French, Italian or Chinese.

You can access the unit via HTTPS using Infinet Wireless self-signed certificate from the Maintenance menu of web interface. The "HTTPS Connection" link is available in the right side of the login form.



		HTTPS Connection
	'	
User Name:		
Password:		
Login		