Connecting to the device

Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer. \oslash

To the certification exam

- Preliminary wireless devices configuration
- Profiles configuration in InfiPOCKET
- Alignment

Preliminary wireless devices configuration

To perform the alignment, it is necessary to pre-configure the Infinet wireless device, it includes the following steps:



- d. Quanta 5/Quanta 6
- e. Quanta 70

Profiles configuration in InfiPOCKET

To obtain the data required for alignment, an SNMP profile must be created in the InfiPOCKET application with SNMP settings match to the wireless device.

- 1. Proceed to the "SNMP Profiles" section of the main menu. Click the "Create SNMP Profile" button.
- 2. Fill in the form with SNMP profile parameters. The values must match the device's settings to which you are connecting:
 - a. Arbitrary profile name.
 - b. SNMP version.
 - c. Access credentials.
- 3. Click the "Save SNMP Profile" button.



Alignment

To start the alignment, connect to a wireless device via SNMP, using following procedure:

- 1. In the "Alignment" section, fill out the connection form:
 - wireless device IP address.
 - network port used for SNMP connection.
 - SNMP profile of the local device.
 - SNMP profile of the remote device, by default the profile set for the local device is used.
- 2. Click the "Connect" buttom.
- 3. Confirm the wireless device was pre-configured and proceed to the alignment step.

Title

