

Security settings



Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

[To the certification exam](#)

The "Security settings" section allows to configure device access and security settings.

This section includes following subsections:

- [Administrator access](#)
- [Radius AAA](#)
- [Command line interface](#)
- [Network access](#)
- [Radio authentication settings](#)

Administrator access

Here you may change system administrator account login and password, to change the identification data, click the "Change admin password" button. We strongly recommend you to set a login and password after the first login to the device.

Changing admin account settings

Login:

Password:

Confirm password:

Reset

Save

Cancel

Figure - Admin access

Radius AAA

Here you may configure a device access control using a remote RADIUS server.

Parameter	Description
Address	Set the RADIUS server IP address.

Title

Port	Set the RADIUS server port.
Secret	Set the server password.

Radius server parameters description

Radius AAA

Enabled: ☐

Address: : Port: Secret:

Figure - RADIUS parameters

Command line interface

Allows to enable / disable remote device control by the command line using Telnet and SSH protocols.

SSH (Secure Shell) protocol provides secure remote control to network devices. Its functionality is similar to the Telnet protocol, but, unlike Telnet, SSH encodes all protocol messages, including transmitted passwords. By default, only access via Telnet is enabled.

Command line interface

SSH: ☐

Telnet: ☒

Figure - Access protocols

Network access

This section is used to create a list of subnets from which access to the device will be allowed.

Network access whitelist

IP address	Subnet mask
<input type="text"/>	<input type="text"/>

+ Add subnet

Figure - Network access

Radio authentication settings

Units at both ends of the wireless link should authorize each other before link establishment. Access key must be up to 64 characters long, without spaces and must be the same at both ends of the link.

Radio authentication settings

Access key:

	Apply
--	-------

Unit parameters description