# **RIP configuration**

Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

To the certification exam

## Table of contents

- Table of contents
- Description
- Task
- Solution
- Additional materials

### Description

The InfiNet devices of the InfiLINK 2x2, InfiMAN 2x2, InfiLINK Evolution, InfiMAN Evolution families have two modules for configuring RIP: rip and arip. The difference between them is in the interoperability with the OSPF protocol, which is not present in the rip module, thus it is recommended to configure the devices using the arip module. Due to the recommendation, this article will describe the RIP configuration using the arip module.

The RIP configuration is performed only via CLI. A separate command shell with several modes is used to configure the RIP protocol (Figure 1). The transition to each mode is performed using the commands with the same name. A detailed description of the commands is available in the Technical documentation.

### \Lambda ΝΟΤΕ

An configuration example is given for the InfiLINK 2x2, InfiMAN 2x2 families devices, pay attention to the name of the radio interface on your devices during the scheme implementation.

Mode name	Description
Basic	The basic RIP mode is used to analyze the output of the diagnostic commands and to switch to the configuration mode. The switching to the basic mode is performed from the WANFleX command shell using the "arip" command. BS_1#1> arip RIP>
RIP configuration	The configuration mode allows to manage the RIP service running on the device and proceed to the configuration modes: router, interfaces or route-maps. The switching to the RIP configuration mode is performed from the basic mode using the "config" command. RIP> config RIP(config)#
RIP router configuration	In the router configuration mode, basic RIPF settings can be made. The mode allows to configure the announced networks, router ID, etc. The switching to the RIP router configuration mode is performed from the configuration mode using the "router" command. RIP(config)# router RIP(config-router)#





Figure 1 - Switching between the RIP command shell modes

Each RIP shell mode provides help by displaying the full list of supported commands. To display the list, use the "help" command.

The routing table can be displayed using one of the following commands:



### Task

Let's take a look at the step by step configuration of the RIP protocol on the InfiNet devices, using the following scheme (Figure 2):

- the network consists of three wireless devices: BS1, CPE2 and CPE3 which are connected through wireless links;
- subnet 172.16.0.0/29 is assigned to the wireless network;
- each wireless device has a connection to a wired segment: BS1 is connected to the 10.10.10.0/24 network, CPE2 to the 10.10.20.0/24 network, CPE3 to the 10.10.30.0/24 network;
- three static routes are configured on the CPE3 wireless device towards the networks 192.168.6.0/28, 192.168.7.0/28 and 192.168.8.0/28. The third-party router R1 is used as a gateway;
- an IP address from the 192.168.0.0/24 network is assigned to the loopback interface of each wireless device.

Task: configure the RIP protocol on the wireless devices in order to add information about all the networks in the scheme to the routing table of each router. The BS1 device should be used as default gateway on the CPE2 and CPE3 devices.



Figure 2 - Network scheme for the RIP configuration

### Solution

The devices will be configured step-by-step. In addition to the RIP configuration, static routes will be used (see Static routing) for providing connectivity with LAN-6, LAN-7 and LAN-8.

In order to highlight several available features, different approaches will be used when configuring RIP on the wireless devices.

#### **Pre-configuration**

Description	Perform a preliminary configuration of the devices, consisting of the following steps:
	<ul> <li>Configure the device IDs.</li> <li>Remove the svi1 interface.</li> <li>Assign IP addresses to the network interfaces, according to the scheme.</li> <li>Add static entries to the routing table.</li> <li>Disable switching.</li> <li>Establish the wireless links.</li> </ul>
B51	Set the device ID system prompt BS_1 Remove the svil interface ifc svil destroy Assign IP addresses ifc eth0 10.10.10.1/24 ifc rf5.0 172.16.0.1/29 ifc lo0 192.168.0.1/32 Disable switching switch stop Establish the radio link rf rf5.0 band 20 rf rf5.0 freq 5000 mint rf5.0 -name "BS_1" mint rf5.0 -type master
	mint rf5.0 -type master

# Title

CPE2	Set the device ID system prompt CPE_2 Remove the svil interface ifc svil destroy Assign IP addresses ifc eth0 10.10.20.2/24 ifc rf5.0 172.16.0.2/29 ifc lo0 192.168.0.2/32 Disable switching switch stop Establish the radio link mint rf5.0 -name "CPE_2" mint rf5.0 -type slave mint rf5.0 prof 1 -band 20 -freq 5000 -type slave
CPE3	<pre>Set the device ID system prompt CPE_3 Remove the svil interface ifc svil destroy Assign IP addresses ifc eth0 10.10.30.3/24 ifc rf5.0 172.16.0.3/29 ifc lo0 192.168.0.3/32 Add static routes route add 192.168.5.0/28 10.10.30.1 route add 192.168.6.0/28 10.10.30.1 Disable switching switch stop Establish the radio link mint rf5.0 -name "CPE_3" mint rf5.0 -type slave mint rf5.0 prof 1 -band 20 -freq 5000 -type slave</pre>

**RIP configuration** 

Description	Configure the RIP protocol according to the scheme.
	Step 1: start the RIP daemon.
	Step 2: define the interfaces where RIP should be started:
	<ul> <li>BS1: the lo0 and radio interfaces;</li> <li>CPE2: all interfaces;</li> <li>CPE3: all interfaces.</li> </ul>
	In CPE2's configuration, the range of networks used in RIP will be set as a single entry: 0.0.0.0/0. This entry includes all networks and enables the RIP support on all router's interfaces; when one of the CPE2's interfaces is connected to a new network, this network will be immediately announced via RIP. This approach doesn't require any additional RIP configuration, but decreases the control over the announcements.
	On the BS1 and CPE3 routers, we will set only those networks that are associated with the interfaces participating in the RIP's operation.
	Step 3: redistribute the directly connected networks on BS1 and the static routes on the CPE3 router.
	<b>Step 4:</b> configure passive interfaces. The eth0 interface of CPE3 is connected to the external router R1, therefore it is necessary to block the transmission of the routing information between them. To ensure this, the eth0 interface of CPE3 must be configured as passive
	Step 5: announce the default route, specifying BS1 as the gateway.
BS1	Start the PID daemon
	arip start
	Start RIP on the interfaces
	arip
	config
	router network 172.16.0.0/29
	Connected routes redistribution
	artp
	contrg
	redistribute connected
	Default route announcement
	arip
	config
	router default-information originate
CPE2	Start the RIP daemon
	arip start
	Start RIP on the interfaces
	arip
	Config
	rourer

# Title

CPE3	Start the RIP daemon
	arip start
	Start RIP on the interfaces
	arip
	config
	router
	network 10.10.30.0/24
	network 172.16.0.0/29
	network 192.168.0.3/32
	Static routes redistribution
	arip
	config
	router
	redistribute kernel
	Configuration of the passive interfaces
	passive-interface eth0

# Command output analysis

### Routing table

Description	The routing tables of the v successfully exchanged ro	wireless devices contain er uting information and add	ntries about each ed it to the FIB.	subnet show	n in the so	cheme. This means that the devices have
	Note that the routing tabl interfaces have been adde	es contain also routes to t ed to RIP in various ways:	he addresses assi	igned to the lo	oopback i	nterfaces of the other wireless devices. These
	<ul> <li>BS1: redistribution o</li> <li>CPE2: the device adv</li> <li>CPE3: the network a</li> </ul>	f a directly connected netw vertises all the networks to ssigned to the loopback in	work; which it is conne terface is explicit	ected because ly announced	e of the co	onfiguration of the 0.0.0.0/0 network;
	Also pay attention to the other devices that support F The CPE3 router redistribut /24, 192.168.7.0/24 and 1	default route on the CPE2 RP, indicating itself as a ga utes the static routes, ther 92.168.8.0/24.	and CPE3 devices teway. At the sar efore, the routing	s. According to ne time, the c g tables of BS	o the conf default rou 1 and CPE	figuration, BS1 announces the default route to all ute is absent from the BS1's routing table. 2 contain paths towards the networks 192.168.6.0
BS1	BS_1#1> netstat Routing tables	-r				
	Destination	Gateway	Flags	Refs	Use	Interface
	10.10.10.0/24	link#2	UC	0	0	eth0
	10.10.20.0/24	172.16.0.2	UG3	0	0	rf5.0
	10.10.30.0/24	172.16.0.3	UG3	0	0	rf5.0
	127.0.0.1	127.0.0.1	UH	3	106	100
	172.16.0.0/29	link#3	UC	0	0	rf5.0
	192.168.0.1	192.168.0.1	UH	0	0	100
	192.168.0.2	172.16.0.2	UGH3	0	0	rf5.0
	192.168.0.3	172.16.0.3	UGH3	0	0	rf5.0
	192.168.6.0/28	172.16.0.3	UG3	0	0	rf5.0
	192.168.7.0/28	172.16.0.3	UG3	0	0	rf5.0
	192.168.8.0/28	172.16.0.3	UG3	0	0	rf5.0
	224.0.0.0/8	127.0.0.1	UGS	0	346	100

# Title

Routing tables	-				
Destination	Gateway	Flags	Refs	Use	Interface
default	172.16.0.1	UG3	0	0	rf5.0
10.10.10.0/24	172.16.0.1	UG3	0	0	rf5.0
10.10.20.0/24	link#2	UC	0	0	eth0
10.10.30.0/24	172.16.0.3	UG3	0	0	rf5.0
127.0.0.1	127.0.0.1	UH	3	100	100
172.16.0.0/29	link#3	UC	0	0	rf5.0
192.168.0.1	172.16.0.1	UGH3	0	0	rf5.0
192.168.0.2	192.168.0.2	UH	0	0	100
192.168.0.3	172.16.0.3	UGH3	0	0	rf5.0
192.168.6.0/28	172.16.0.3	UG3	0	0	rf5.0
192.168.7.0/28	172.16.0.3	UG3	0	0	rf5.0
192.168.8.0/28	172.16.0.3	UG3	0	0	rf5.0
224.0.0.0/8	127.0.0.1	UGS	0	703	100
Routing tables		_	_		
Destination	Gateway	Flags	Refs	Use	Interface
default	172.16.0.1	UG3	0	0	rf5.0
	172.16.0.1	TIC 2		~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	+
10.10.10.0/24	1,2,10,0,11	003	0	0	r15.0
10.10.10.0/24 10.10.20.0/24	172.16.0.2	UG3	0	0	r15.0 rf5.0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24	172.16.0.2 link#2	UG3 UC	0 0 0	0	r15.0 rf5.0 eth0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1	172.16.0.2 link#2 127.0.0.1	UG3 UC UH	0 0 3	0 0 84	r15.0 rf5.0 eth0 lo0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29	172.16.0.2 link#2 127.0.0.1 link#3	UG3 UG3 UC UH UC	0 0 3 0	0 0 84 0	rf5.0 eth0 lo0 rf5.0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29 192.168.0.1	172.16.0.2 link#2 127.0.0.1 link#3 172.16.0.1	UG3 UC UH UC UGH3	0 0 3 0 0	0 0 84 0 0	rf5.0 eth0 lo0 rf5.0 rf5.0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29 192.168.0.1 192.168.0.2	172.16.0.2 link#2 127.0.0.1 link#3 172.16.0.1 172.16.0.2	UG3 UC UH UC UGH3 UGH3	0 0 3 0 0 0	0 0 84 0 0 0	rf5.0 eth0 lo0 rf5.0 rf5.0 rf5.0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29 192.168.0.1 192.168.0.2 192.168.0.3	172.16.0.2 link#2 127.0.0.1 link#3 172.16.0.1 172.16.0.2 192.168.0.3	UG3 UC UH UC UGH3 UGH3 UH	0 0 3 0 0 0 0	0 0 84 0 0 0 0	rf5.0 eth0 lo0 rf5.0 rf5.0 rf5.0 lo0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29 192.168.0.1 192.168.0.2 192.168.0.3 192.168.0.3	172.16.0.2 1ink#2 127.0.0.1 1ink#3 172.16.0.1 172.16.0.2 192.168.0.3 10.10.30.1	UG3 UC UH UC UGH3 UH UH UGS	0 0 3 0 0 0 0 0	0 0 84 0 0 0 0 0	rf5.0 eth0 lo0 rf5.0 rf5.0 rf5.0 lo0 eth0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29 192.168.0.1 192.168.0.2 192.168.0.3 192.168.6.0/28 192.168.7.0/28	172.16.0.2 link#2 127.0.0.1 link#3 172.16.0.1 172.16.0.2 192.168.0.3 10.10.30.1 10.10.30.1	UG3 UC UH UC UGH3 UH UGS UGS		0 0 84 0 0 0 0 0 0	rf5.0 eth0 lo0 rf5.0 rf5.0 rf5.0 lo0 eth0 eth0
10.10.10.0/24 10.10.20.0/24 10.10.30.0/24 127.0.0.1 172.16.0.0/29 192.168.0.1 192.168.0.2 192.168.0.3 192.168.6.0/28 192.168.7.0/28 192.168.8.0/28	172.16.0.2 1ink#2 127.0.0.1 1ink#3 172.16.0.1 172.16.0.2 192.168.0.3 10.10.30.1 10.10.30.1 10.10.30.1	UG3 UC UH UC UGH3 UGH3 UH UGS UGS UGS		0 0 84 0 0 0 0 0 0 0 0 0	r15.0 rf5.0 eth0 lo0 rf5.0 rf5.0 rf5.0 lo0 eth0 eth0 eth0

### Additional materials

### **Online courses**

1. InfiLINK 2x2 / InfiMAN 2x2: Initial Link Configuration and Installation.

#### Other

- 1. If config command (interfaces configuration)
- 2. route command (static routes configuration)
- 3. ARDA (Aqua Router Daemon)
- 4. arip command
- 5. rip command