

Redundancy w/o aggregation and InfiMUX



Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.

[To the certification exam](#)

- [Description](#)
- [Configuration Example](#)




CAUTION

Configurations from the scenarios below are examples that demonstrate the potential capabilities of the Infinet Wireless devices. The configurations may vary depending on the model and firmware version. We do not recommend copying this solutions to the hardware without checking.

Description

It is easy to fully reserve a connection by combining two radio channels into one MINT domain. The traffic path will be automatically selected based on the quality of each radio link in this case.



Configuration Example

A management is VLAN 100 in switch group #100. A transport of user data is in switch group #1.

- Configure Master 1 and Slave 1 as the main link.

Master 1

```
rf rf5.0 band 40
rf rf5.0 mimo
rf rf5.0 freq 5000 bitr 300000 sid 10101010 burst
rf rf5.0 txpwr 25 pwrctl distance auto
dfs rf5.0 dfsoff
mint rf5.0 -roaming leader
mint rf5.0 -type master
mint rf5.0 -name "Master 1"
mint rf5.0 -key "123456789"
mint rf5.0 poll start
ifc svi100 up
ifc vlan100 vlan 100 vlandev eth0 up
sw group 100 add vlan100 rf5.0
svi 100 group 100
ifc svi100 192.168.1.1/24
sw group 100 stp on
sw group 100 start
```

Slave 1

```
rf rf5.0 band 40
rf rf5.0 mimo
rf rf5.0 burst
dfs rf5.0 dfsoff
mint rf5.0 prof 1 -band 40 -freq 5000 -bitr 300000 -sid 10101010 -nodeid 00020 -type slave -netid 0 -
minbitr 30000 -autobitr -mimo -key "123456789"
mint rf5.0 -name "Slave 1"
ifc svi100 up
ifc vlan100 vlan 100 vlandev eth0 up
sw group 100 add vlan100 rf5.0
svi 100 group 100
ifc svi100 192.168.1.2/24
switch group 100 order 1
sw group 100 stp on
sw group 100 start
```

- Configure Master 2 and Slave 2 as a backup link.

Master 2

```
rf rf5.0 band 40
rf rf5.0 mimo
rf rf5.0 freq 5100 bitr 300000 sid 10101010 burst
rf rf5.0 txpwr 25 pwrctl distance auto
dfs rf5.0 dfsoff
mint rf5.0 -roaming leader
mint rf5.0 -type master
mint rf5.0 -name "Master 2"
mint rf5.0 -key "123456789"
mint rf5.0 poll start
ifc svi100 up
ifc vlan100 vlan 100 vlandev eth0 up
sw group 100 add vlan100 rf5.0
svi 100 group 100
ifc svi100 192.168.1.3/24
switch group 100 order 1
sw group 100 stp on
sw group 100 start
```

Slave 2

```
rf rf5.0 band 40
rf rf5.0 mimo
rf rf5.0 burst
dfs rf5.0 dfsoff
mint rf5.0 prof 1 -band 40 -freq 5100 -bitr 300000 -sid 10101010 -nodeid 00040 -type slave -netid 0 -
minbitr 30000 -autobitr -mimo -key "123456789"
mint rf5.0 -name "Slave 2"
ifc svi100 up
ifc vlan100 vlan 100 vlandev eth0 up
sw group 100 add vlan100 rf5.0
svi 100 group 100
ifc svi100 192.168.1.4/24
switch group 100 order 1
sw group 100 stp on
sw group 100 start
```

- Create united MINT domain.

Master 1

```
ifc prf0 up
prf 0 parent eth0
mint prf0 -name "Master 1 prf"
mint prf0 -nodeid 00050
mint prf0 -type master
mint prf0 -mode fixed
mint prf0 -key "123456789"
mint prf0 -authmode public
mint prf0 start
mint join rf5.0 prf0
```

Slave 1

```
ifc prf0 up
prf 0 parent eth0
mint prf0 -name "Slave 1 prf"
mint prf0 -nodeid 00060
mint prf0 -type master
mint prf0 -mode fixed
mint prf0 -key "123456789"
mint prf0 -authmode public
mint prf0 start
mint join rf5.0 prf0
```

Master 2

```
ifc prf0 up
prf 0 parent eth0
mint prf0 -name "Master 2 prf"
mint prf0 -nodeid 00070
mint prf0 -type master
mint prf0 -mode fixed
mint prf0 -key "123456789"
mint prf0 -authmode public
mint prf0 start
mint join rf5.0 prf0
```

Slave 2

```


ifc prf0 up
prf 0 parent eth0
mint prf0 -name "Slave 2 prf"
mint prf0 -nodeid 00080
mint prf0 -type master
mint prf0 -mode fixed
mint prf0 -key "123456789"
mint prf0 -authmode public
mint prf0 start
mint join rf5.0 prf0

```

- Configure switch groups.

CAUTION

If you do not exclude the interface eth0 on one of the devices or do not enable STP, then there will be a loop.



The STP protocol is used to eliminate the loop in the example below.

Master 1

```

switch group 1 add eth0 prf0
sw group 1 stp on
switch group 1 start

```

Master 2

```

switch group 1 add eth0 prf0
sw group 1 stp on
switch group 1 start

```

Slave 1

```

switch group 1 add eth0 prf0
sw group 1 stp on
switch group 1 start

```

Slave 2

```
switch group 1 add eth0 prf0
sw group 1 stp on
switch group 1 start
```