

Installation Preparations of InfiNet Wireless R5000



Successfully pass the free certification exam at IW Academy and become an Infinet Certified Engineer.





[To the certification exam](#)

- [Packing List](#)
- [Additional Items Required](#)
- [Precautionary Measures](#)

This section describes all the supplies required to install the R5000 system components and the items included in each installation package.

Before the installation, please make sure you have all necessary parts and accessories.

Packing List

Component	Description
	<ul style="list-style-type: none"> • Outdoor unit (ODU) <ul style="list-style-type: none"> • Integrated antenna model or connectorized model according to the Purchase Order
	<ul style="list-style-type: none"> • Mounting kit <ul style="list-style-type: none"> • Assembling kit for mounting the ODU on standard pole, wall or thick pipe (vertical /horizontal) • The model depends on the ODU model
	<ul style="list-style-type: none"> • Indoor power supply (IDU) <ul style="list-style-type: none"> • The model depends on the ODU model
	<ul style="list-style-type: none"> • Power cord <ul style="list-style-type: none"> • The model depends on the region, according to the Purchase Order
	<ul style="list-style-type: none"> • Unshielded RJ-45 plug (to be used at ODU end) <ul style="list-style-type: none"> • Quantity depends on the ODU model

	<ul style="list-style-type: none"> • Shielded RJ-45 plug (to be used at IDU end) - 1 pcs
	<ul style="list-style-type: none"> • RJ-45 plug cap - 1 pcs
	<ul style="list-style-type: none"> • Cable gland <ul style="list-style-type: none"> • Quantity depends on the ODU model
	<ul style="list-style-type: none"> • Clamps - 2 pcs <ul style="list-style-type: none"> • Supplied with R5000-Smn(c) 5-6 GHz, 19 dBi models

Table - Packing List

Additional Items Required

Parts and Materials

- External antenna (only for the connectorized ODU models)
- Low-loss RF cables - **CAB-RF-1M** cable is recommended (only for the connectorized ODU models)
- Antenna pole (if necessary)
- Required grounding circuit, including cables and rods (if these are not already in place at the installation site).

Tools

- Screwdrivers set
- Pliers/Wrenches
- Spanners set
- Connectors isolating set:
 - Raw rubber
 - Thermal shrinkage tube
 - Scissors
 - Fan
 - Mantling gun
- Additional equipment:
 - GPS receiver or area map (with compass and alidade)
 - Big zoom binoculars

Optional Accessories

- AUX-ODU-INJ-G DC injector with lightning protection
- AUX-ODU-LPU-G or AUX-ODU-LPU-L lightning protection unit
- AUX-ODU-SYNC synchronization unit.



NOTE

Accessories are available from InfiNet Wireless.

Precautionary Measures



CAUTION

Before you start the installation, please read this section very carefully.

Antennas are installed on the roof tops or on the building walls. This work must be accomplished only by personnel having special skills and experience in this area.

Antennas and cables are electric conductors. Incidental electrostatic strikes may occur during the system installation. This can lead to equipment damage or may hurt the personnel. While installing or changing the elements of the antenna-feeder system, one must make sure that open metal parts are temporarily grounded.

Do not install the antenna close to the electric power lines. Antenna and antenna pole have to be installed in such a way that, during their assembling, disassembling and repairing, they do not have any contact with power lines.

Basic precautionary measures that must be fulfilled during the installation are as follows:

- Do not stay on the roof top in windy or rainy weather, during thunderstorms or when the working zone is covered with snow or ice
- Do not touch the antennas, antenna poles, cables and lightning arrestors during thunderstorms
- Antenna cable must be grounded at all times.

In case of failure, any manipulation of the equipment is allowed to trained personnel only.